

STARTING GUIDE WITH MECKLOCK FITTED

APPLICABLE UK FORKS MACHINES: ALL

Battery Management

The guide will help prevent starting and battery issues that may occur when using a UKF machine. Below will list good working practices to increase and prevent battery failure.

- Turn off and remove the battery isolator when machines are parked up to avoid charge drainage. Isolator key located under the cab next to the steps.
- **NOTE. After removing the ignition key wait 15 seconds before removing the isolator key as this can cause an error code to appear.**

Isolator Key



- In cold weather do not attempt to start machinery with any auxiliary circuits switched on i.e. lights, wipers or heater blowers. This will draw more power out of the battery during a critical stage of load.



- When starting a machine allow it to run for at least 30-mins before switching the engine off to give time for batteries to re charge. This is essential in winter months when lights, wipers and blowers are almost always on and place additional demand on the machine battery.

STARTING GUIDE WITH MECKLOCK FITTED (CONT.)

APPLICABLE UK FORKS MACHINES: ALL

Start Procedure

1. Fit battery isolator key turn fully clockwise.

Isolator Key



2. If fitted insert and turn Meck-lock key fully clockwise.

Mecklock Key



| Location | 520-40 | 525-60 | 531-70 | 533-105 | 535-140 | 540-140 | 540-170 | 540-180 | 540-200 |
|-------------------------|--------|--------|--------|---------|---------|---------|---------|---------|---------|
| Under The Seat | ✓ | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ |
| Next To Key Pad | ✗ | ✓ | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ |
| Below Stabiliser levers | ✗ | ✓ | ✓ | ✓ | ✓ | ✓ | ✗ | ✓ | ✗ |
| Below Joy stick | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ | ✓ | ✗ | ✓ |

3. Put the machine gear lever in the neutral position.

Symbol on dash to show machine in neutral



STARTING GUIDE WITH MECKLOCK FITTED (CONT.)

APPLICABLE UK FORKS MACHINES: ALL

| Location | 520-40 | 525-60 | 531-70 | 533-105 | 535-140 | 540-140 | 540-170 | 540-180 | 540-200 |
|-----------------------------|--------|--------|--------|---------|---------|---------|---------|---------|---------|
| L/H Side Off Steering Wheel | ✗ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Joy Stick | ✓ | ✓ | ✗ | ✗ | ✗ | ✗ | ✓ | ✗ | ✓ |

Battery

- Sit on the seat with the seat belt engaged.

Seat Switch Symbol



Seat Belt Symbol



Note: The indication symbols will only illuminate if the operator is not sat on the seat or the seat belt is not engaged.